

Technical Brief AN236Rev A

Serial Communications RS232, RS485, RS422

By John Sonnenberg

Raveon Technologies Corp

Summary

Electronic communications is all about interlinking circuits (processors or other integrated circuits) to create a symbiotic system. For those individual circuits to swap information, they must share a common standard communication protocol. Many communication protocols have been designed to achieve data exchange.

The most common serial communication protocols are RS232, RS485, RS422, USB, and Ethernet. But because USB and Ethernet require powerful interfaces with complex protocols, many efficient devices utilized RS232, RS485, and RS422 which is what this note is all about.

Protocol Comparison Chart

	RS-232	RS-422	RS-485
Cable	Single ended	Single ended multi- drop	Multi-drop
Number of Devices	1 transmitter 1 receiver	1 transmitter 10 receivers	32 transmitters 32 receivers
Communication Mode	Full duplex	Full duplex, Half duplex	Full duplex, Half duplex
Maximum Distance	50 feet at 19.2 kbps	4000 feet at 100 kbps	4000 feet at 100 kbps
Max Data Rate (50 feet)	1 mbps	10 mbps	10 mbps

Serial Protocols

The RS232, RS485, RS422 serial protocols only relate to the hardware interface, not the software protocols used to make the devices communicate. There are many protocols that exist in the market place so one cannot assume interoperability between different manufacturers of "RS232" ports.

To define Instruments that supports a mixture of industry standard and proprietary serial protocols:

Modbus RTU

This protocol is used in industrial applications and most SCADA PLC's have drivers for Modbus RTU. The Modbus protocol is well published and every manufacturer determines its own addressing scheme. The manufacturer must supply the addressing scheme, register type, and Modbus commands that is supports.

ASCII protocol

ASCII is popular because it is easier than Modbus to write your own driver in a PLC or a PC. Most every manufacturer's protocols are not usually compatible.

The Advantages of RS485 and RS422 vs RS232


RS485 and RS422 use differentiation. Two wires are required for each signal. The figure below shows a single RS485 / RS422 signal being transmitted. To transmit a logic 1, line B is high and line A is low. To transmit a logic 0, line B is low and line A is high. The advantage of this arrangement is that signals can be transmitted faster and over greater distances than is possible with a single wire.

The main difference between RS422 and RS485 is the types of communications allowed. RS422 allows only one-way (simplex) communications between one driver, and as many as ten receiving devices. To control devices and need no feedback from them, RS-422 multidrop network will work well. RS485 was designed to address the multi-drop limitation of RS422, allowing up to 32 devices to communicate.

RS-232

An RS232 serial bus consists of just two communication wires - one for sending data and another for receiving. As such, serial devices should have two serial pins: the receiver, RX, and the transmitter, TX. Because the communication data is based upon the voltage on the wires, relative to the ground level, a ground connection must be made between devices that communicate with RS-232. Here is an RS232 wiring diagram:

RS232 Wiring



A digital 1 voltage is: -3V to -25V A digital 0 voltage is: +3V to +25V RS232 data is sent serially, each bit is sent one after the next because there is only one data line in each direction. This mode of data transmission also requires that the receiver knows when the actual data bits are arriving so that it can synchronize itself to the incoming data. To achieve this a logic 0 is sent as a synchronization start bit.

RS422 (Single Driver Communications)

RS422 is designed to be tolerant of noise and forgiving of long cable runs. It is typically used between one transmitter receiver pair to one other transmitter receiver pair. Each output can drive up to 10 receivers. It achieves this by using a differential current drive output which has high immunity to noise. The noise immunity enables RS422 systems to operate over very long connections, much better than RS232, US, and Ethernet.

Each signal uses two wires to pass the data. The differential voltage on the A and B wires represent the digital value. If B>A the value is 1. If A>B then value is 0.

Input Signal	Α	В	Output Signal
0	1	0	0
1	0	1	1

RS422 Wiring



RS422A Standard Specifications


1 Driver, up to 10 Receivers

Line Length for Max Data Rate:

- 40 Feet = 12m 10 Mbits/sec
- 400 Feet = 122m 1 Mbits/sec
- 4000 Feet = 1219m 100 kbits/sec

A multi-drop wiring has many desirable advantages, RS422 devices cannot be used to construct a truly multi-point network. A true multi-point network consists of multiple drivers and receivers connected on a single bus, where any node can transmit or receive data. RS422 networks are often used in a half-duplex mode,

RS422 Multi Drop Wiring



RS485 (Multiple Driver Communications)

RS485 is similar to RS422 upon which it is based. The main difference is that up to 32 transmitter receiver pairs may be present on the RS485 lines at one time. RS-485 is generally a 2-wire half duplex system. AN RS485 4-wire full duplex system is very similar to RS-422.


RS485 is still popular. It is similar to the RS422 upon which it is based. The RS485 port has been used for many years. RS485 has many advantages over both RS232 and USB when it comes to applications in noisy industrial environments. RS422 devices can be used on an RS485 bus network if they are only used as recipients.

The Primary features of RS-485 are:

- Balanced interface
- Multipoint operation from a single 5-V supply
- -7-V to +12-V bus common-mode range
- Up to 32 unit loads

The main difference between RS422 and RS485 is that up to 32 transmitter receiver pairs may be present on the line at one time on RS485. A 120 Ohm resistor must be used to terminate the main line. The full-duplex implementation requires two signal pairs, (four wires).

RS485 Full Duplex Wiring



RS485A Standard

Up to 32 Driver/Receiver Pairs

Line Length Max Data Rate

- 40 Feet = 12m 10 Mbits/sec
- 400 Feet = 122m 1 Mbits/sec
- 4000 Feet = 1219m 100 kbits/sec

In half-duplex, only one signal pair (A, B) is used. When instruments are described as having an RS485 interface this tells you nothing for sure about the signals being transmitted. Usually though only the Transmit Data (TX) and Receive Data (RX) of a normal serial port are converted to RS485 or RS422. The other signals of the serial port are not used. Three arrangements are commonplace: Write only, 4-wire (full duplex) and 2-wire (half duplex). The "2-wire" RS-485 connection is shown below.

RS485 Half Duplex Wiring Structure HOST TX+(Y) TX-(Z) B RX-(B) RX+(A) DEVICE 1 DEVICE 2 Data+ Data+ Data+ Data+ Data+ Data+ Data-

RS485 half-duplex can use just two wires to communicate with up to 32 device, one at a time. Each device has the ability to turn off its output drivers, so only the one device that is linking to the host outputs a signal on its TX lines. Terminating Resistors (RT) are connected across the ends of the A B wires. Cable trunk is commonly terminated with 120 ohm resistors. Because you are sending and receiving on the same two wires, you need to enable and disable the transmitter at the correct time so that you may perform proper communications.

Termination Resistors

Termination resistors should be placed on both ends of the twisted pair of wires. The impedance value should be the same value of the characteristic impedance of the twisted pair and should be placed at the far ends of the cable. For cables that are 2000 feet or less, a termination resistor is not needed at baud rates of 9600bps or less.

If a termination resister is required, a 120Ω or greater should be used. No more than 2 termination resistors should be used, one at each end of the RS485 transmission line.



The A B wires should always be looped around together. Looping the wires helps reduce noise, and when electrical, magnetic, and RF noise couples onto the A B cable, by looping the cable, the noise goes equally onto both A and B wires, so the differential data has no differential noise.

For additional information, contact:

Raveon Technologies Corporation

2320 Cousteau Court Vista, CA 92081 - USA

Phone: 1-760-444-5995 Fax: 1-760-444-5997 Email: sales@raveon.com